

大洗
OARAI

2026 年

満 潮										干 潮										満 潮										干 潮									
日	時 分	cm	時 分	cm	時 分	cm	時 分	cm		日	時 分	cm	時 分	cm	時 分	cm	時 分	cm		日	時 分	cm	時 分	cm	時 分	cm	時 分	cm											
1月	1	3 42	119	12 40	132	.	7 32	108	20 38	-1	4月	1	3 36	119	15 48	121	9 43	36	21 50	34	望	2	3 53	123	16 29	123	10 12	24	22 19	42									
	2	4 33	127	13 40	136	.	8 48	110	21 29	-11		3	4 11	126	17 8	121	10 41	14	22 46	51																			
	3	5 14	131	14 37	141	.	9 41	107	22 16	-15		4	4 30	128	17 47	118	11 10	9	23 12	60																			
	4	5 49	131	15 29	143	.	10 24	101	22 59	-14		5	4 50	128	18 26	113	11 40	7	23 36	67																			
	5	6 20	129	16 18	142	.	11 4	93	23 38	-8	6	5 11	128	19 6	107	12 11	9	23 59	74																				
	6	6 48	127	17 5	137	.	11 44	85			7	5 32	125	19 53	99			12 45	14																				
	7	7 12	125	17 50	129	.	0 14	3	12 25	77	8	5 55	121	21 0	93	0 19	80	13 24	21																				
	8	7 34	124	18 37	117	.	0 46	17	13 9	70	9	6 18	116			0 34	86	14 14	28																				
	9	7 56	124	19 28	105	.	1 15	32	13 59	65	10	下弦	6 42	109					15 28	35																			
	10	8 19	125	20 34	93	.	1 42	48	14 58	61	11		7 7	100					17 7	37																			
	11	下弦	8 44	124	22 28	85	.	2 6	63	16 11	56	12	2 4	101	9 52	91	7 24	90	18 30	35																			
	12		9 15	123		.	2 29	77	17 33	49	13	2 15	106	12 32	95	7 52	77	19 28	33																				
	13		9 56	120		.			18 46	40	14	2 29	110	13 47	104	8 19	62	20 13	33																				
	14		10 58	119		.			19 43	31	15	2 46	115	14 42	114	8 48	44	20 52	37																				
	15		3 56	109	12 15	119	.	7 17	103	20 30	21	16	3 4	119	15 33	122	9 19	26	21 28	44																			
	16		4 20	116	13 21	122	.	8 32	101	21 10	12	17	朔	3 23	124	16 21	127	9 52	9	22 3	53																		
	17		4 46	120	14 12	127	.	9 19	97	21 47	5	18	3 44	128	17 10	127	10 27	-5	22 35	64																			
	18		5 11	122	14 56	131	.	9 55	92	22 21	1	19	4 7	132	18 1	124	11 5	-13	23 5	75																			
	19	朔	5 36	123	15 37	134	.	10 27	86	22 53	-1	20	4 32	135	18 55	117	11 46	-15	23 33	84																			
	20		6 0	124	16 16	135	.	11 0	80	23 23	1	21	4 59	135	19 57	108	12 30	-10	23 59	91																			
	21		6 23	124	16 56	132	.	11 34	73	23 53	6	22	5 28	131	21 19	101			13 21	0																			
	22		6 44	125	17 38	128	.	0 22	16	12 48	59	23	5 59	124			0 24	95	14 21	12																			
	23		7 5	125	18 23	120	.			13 32	52	24	上弦	6 35	113					15 36	24																		
	24		7 26	125	19 15	110	.	0 50	30	14 23	46	25	0 42	100	7 44	99	4 12	97	17 1	33																			
	25		7 46	125	20 20	99	.	1 16	46			26		1 8	103	11 16	92	6 58	83	18 15	39																		
	26	上弦	8 8	125	22 1	90	.	1 41	63	15 28	40	27	1 30	107	13 6	97	7 41	66	19 12	44																			
	27		8 33	125		.	1 57	80	16 51	33		28	1 51	112	14 13	104	8 15	49	19 58	49																			
	28		9 7	124		.			18 20	24		29	2 12	117	15 5	111	8 46	34	20 38	55																			
	29		10 16	121		.			19 37	12		30	2 34	121	15 50	116	9 17	21	21 14	61																			
	30		4 26	117	12 18	122	.	7 56	112	20 37	1																												
	31		4 40	122	13 46	127	.	9 6	104	21 27	-6																												
2月	1	望	5 1	124	14 48	133	.	9 46	94	22 9	-9	5月	1	2 56	125	16 31	119	9 47	11	21 48	67																		
	2		5 22	125	15 39	137	.	10 21	83	22 46	-7		2	3 20	127	17 11	120	10 17	4	22 20	73																		
	3		5 42	125	16 25	137	.	10 55	71	23 19	1		3	3 44	129	17 50	119	10 47	1	22 50	77																		
	4		6 1	125	17 9	132	.	11 29	60	23 48	12		4	4 8	129	18 28	115	11 18	1	23 19	81																		
	5		6 19	126	17 50	124	.			12 4	52		5	4 34	128	19 9	111	11 51	4	23 47	85																		
	6		6 36	127	18 32	114	.	0 14	25	12 40	46		6	5 2	125	19 55	106			12 26	9																		
	7		6 54	128	19 16	104	.	0 37	39	13 18	43		7	5 30	121	20 51	102	0 18	87	13 5	16																		
	8		7 13	127	20 8	93	.	0 57	53	14 1	42		8	6 0	115	22 1	100	0 55	90	13 50	23																		
	9	下弦	7 33	125	21 30	84	.	1 13	66	14 54	43		9	6 36	107	23 14	102	1 54	93	14 45	31																		
	10		7 56	122		.	1 13	77	16 8	44			10	下弦	7 35	97			3 51	91	15 55	38																	
	11		8 23	117		.			17 47	41			11	0 4	105	9 51	90	5 55	82	17 11	44																		
	12		9 8	112		.			19 13	34			12	0 38	108	12 8	92	6 54	67	18 19	50																		
	13		4 15	106	11 18	108	.	7 20	103	20 11	24		13	1 5	113	13 35	102	7 33	49	19 17	57																		
	14		4 12	111	13 4	112	.	8 37	97	20 54	15		14	1 30	118	14 39	113	8 10	30	20 7	64																		
	15		4 25	115	14 5	119	.	9 13	89	21 30	7		15	1 56	123	15 36	121	8 48	11	20 52	73																		
	16		4 42	118	14 53	125	.	9 43	80	22 2	3		16	2 23	129	16 30	127	9 27	-5	21 33	82																		
	17	朔	5 0	121	15 36	130	.	10 13	70	22 33	3		17	2 53	134	17 23	128	10 8	-16	22 12	89																		
	18		5 18	123	16 18	132	.	10 43	59	23 2	7		18	3 26	138	18 17	125	10 52	-21	22 50	95																		
	19		5 36	124	17 0	131	.	11 15	48	23 30	16		19	4 2	140	19 12	120	11 38	-19	23 28	97																		
	20		5 54	126	17 44	126	.	11 48	37	23 56	29		20	4 40	138	20 8	115			12 26	-11																		
	21		6 11	127	18 30	119	.			12 24	29		21	5 22	132	21 2	110	0 10	98	13 16	1																		
	22		6 29	128	19 21	108	.	0 21	44	13 4	24		22	6 10	122	21 53	108	1 4	96	14 8	15																		
	23		6 47	129	20 24	97	.	0 42	60	13 51	23		23	7 11	109	22 38	108	2 22	92	15 3	30																		
	24	上弦	7 6	128	22 25	87	.	0 56	74	14 51	24		24	8 48	97	23 16	110	4 10	84	16 2	44																		
	25		7 27	125		.	0 32	86	16 17	26			25	11 7	91	23 52	113	5 49	71	17 3	56																		
	26		7 48	120		.			18 4	24			26			12 58	94	6 52	56	18 4	66																		
	27		8 5	111		.			19 31	16			27	0 26	118	14 13	102	7 37	41	19 1	74																		
	28		4 3	113	12 42	111	.	8 40	100	20 29	9		28	0 59	121	15 9	109	8 15	28	19 54	81																		
													29	1 32	125	15 55	116	8 50	18	20 41	85																		
													30	2 5	127	16 37	120	9 24	10	21 24	88																		
													31	望	2 37	129	17 15	122	9 57	5	22 2	90																	
3月	1	望	4 6	116	14 3	119	.	9 7	87	21 13	5	6月	1	3 9	131	17 52	122	10 31	3	22 37	90																		
	2		4 19	118	14 59	126	.	9 36	73	21 50	5		2	3 42	131	18 28	120	11 5	3	23 10	91																		
	3		4 34	121	15 46	129	.	10 6	58	22 22	10		3	4 14	131	19 5	118	11 39	5	23 45	91																		
	4		4 50	123	16 28	129	.	10 36	46	22 51	18		4	4 48	128	19 43	115			12 14	9																		
	5		5 7	125	17 8	126	.	11 7	35	23 17	29		5	5 23	124	20 22	114	0 22	90	12 50	15																		
	6		5 24	127	17 48	120	.	11 37	27	23 41	40		6	6 1	118	21 1	113	1 7	90	13 28	23																		
	7		5 41	128	18 27	113	.			12 9	23		7	6 49	110	21 40	114	2 5	88	14 9	33																		
	8		5 59	129	19 8	104	.	0 3	52	12 41	23		8	7 58	101	22 17	115	3 19	83	14 57	44																		
	9		6 17	127	19 55	95	.	0 22	63	13 16	25		9	9 41	94	22 54	117	4 41	73	15 54	57																		
	10		6 37	124	21 4	87	.	0 37	72	13 59	30		10	11 46	95	23 30	120	5 49	58	17 1	70																		
	11	下弦	6 58	119		.	0 38	80	14 57	36			11			13 3																							

大洗
OARAI

2026 年

満 潮										干 潮										満 潮										干 潮									
日	時 分			cm	時 分			cm	時 分			cm	時 分			cm	日	時 分			cm	時 分			cm	時 分			cm										
7月	1	3	30	136	18	14	127	. 10	55	8	23	3	94	10月	1	7	8	129	17	34	150	. 0	16	20	11	53	96												
	2	4	8	136	18	43	127	. 11	28	10	23	38	90		2	8	16	119	17	57	146	. 1	1	24	12	8	105												
	3	4	46	134	19	10	126	. 11	59	14					3	下弦			18	21	140	. 1	58	32															
	4	5	25	130	19	36	126	. 0	15	86	12	30	21		4				18	46	130	. 3	18	41															
	5	6	8	124	20	2	127	. 0	56	82	13	1	30		5				14	33	123	. 5	3	46															
	6	6	58	117	20	27	127	. 1	42	77	13	33	42	下弦	6				14	24	126	. 6	31	46	19	48	102												
	7	8	1	108	20	53	128	. 2	37	70	14	8	57		7	0	34	121	14	35	129	. 7	32	45	20	17	85												
	8	9	28	101	21	22	129	. 3	41	62	14	47	74		8	1	48	130	14	50	133	. 8	17	46	20	48	67												
	9	11	37	100	21	58	130	. 4	51	51	15	35	90		9	2	43	137	15	7	137	. 8	55	51	21	18	52												
	10	14	0	109	22	46	132	. 6	2	38	16	49	105		10	3	30	142	15	26	141	. 9	28	58	21	49	38												
	11	15	24	120	23	52	135	. 7	8	24	18	35	114	朔	11	4	13	144	15	45	145	. 9	59	66	22	20	29												
	12			16	16	129	. 8	9	10	20	10	117	12		4	54	143	16	5	147	. 10	28	75	22	50	24													
	13	1	4	139	16	57	134	. 9	4	0	21	15	114		13	5	35	139	16	26	147	. 10	55	83	23	21	22												
	14	2	10	144	17	32	135	. 9	54	-6	22	4	108		14	6	15	134	16	49	146	. 11	21	90	23	53	25												
	15	3	8	148	18	2	135	. 10	40	-6	22	47	99		15	6	57	127	17	12	143	. 11	46	96															
	16	4	2	149	18	29	133	. 11	22	-1	23	28	90	上弦	16	7	45	120	17	36	139	. 0	28	31	12	9	101												
	17	4	52	146	18	53	132	. 11	59	10					17	8	51	113	18	1	132	. 1	8	39	12	32	106												
	18	5	42	139	19	14	133	. 0	9	80	12	33	24		18				18	27	124	. 1	58	47															
	19	6	31	128	19	35	134	. 0	53	72	13	3	40		19	上弦	13	7	114	18	58	115	. 3	10	55	15	50	113											
	20	7	24	117	19	56	135	. 1	40	66	13	30	57		20	13	27	119	22	1	106	. 4	47	58	19	4	104												
	21	8	28	105	20	19	135	. 2	34	62	13	54	73	下弦	21				13	45	123	. 6	10	58	19	35	91												
	22	10	5	97	20	47	134	. 3	37	59	14	17	87		22	0	27	110	14	2	127	. 7	7	57	20	1	76												
	23			21	22	131	. 4	52	55						23	1	36	119	14	19	132	. 7	52	57	20	29	60												
	24			22	17	128	. 6	9	49						24	2	29	129	14	38	136	. 8	30	60	20	58	42												
	25	15	43	118	23	42	127	. 7	16	42	18	47	114		25	3	16	137	14	57	140	. 9	6	66	21	30	26												
	26				16	6	125	. 8	9	35	20	18	111	望	26	4	3	143	15	19	145	. 9	40	74	22	4	13												
	27	1	0	129	16	31	129	. 8	53	27	21	8	107		27	4	49	144	15	42	149	. 10	12	83	22	41	4												
	28	1	59	133	16	55	131	. 9	32	21	21	44	101		28	5	37	142	16	8	151	. 10	43	92	23	20	2												
	29	2	45	138	17	19	133	. 10	6	17	22	17	95		29	6	29	135	16	35	151	. 11	11	100															
	30	3	27	141	17	41	134	. 10	38	16	22	49	88		30	7	27	127	17	5	148	. 0		5	11	39	106												
	31	4	6	142	18	3	135	. 11	8	18	23	21	81	31	8	39	119	17	38	142	. 0	53	14	12	9	110													
8月	1	4	46	141	18	23	136	. 11	37	24	23	55	74	11月	1	10	17	115	18	17	131	. 1	50	25	12	53	112												
	2	5	27	137	18	42	137	. 0			12	4	33		2	下弦	11	50	115	19	24	117	. 3	1	38	15	9	112											
	3	6	11	132	19	2	138	. 0	31	67	12	31	45		3	12	31	118	22	34	108	. 4	24	48	18	12	99												
	4	7	0	124	19	21	138	. 1	11	60	12	57	59		4				12	57	121	. 5	43	56	19	10	81												
	5	7	58	115	19	42	139	. 1	56	55	13	22	75		5	0	41	112	13	20	126	. 6	45	62	19	48	63												
	6	下弦	9	21	107	20	5	139	. 2	53	50	13	42	91	6	1	54	120	13	43	131	. 7	35	68	20	23	47												
	7			20	36	138	. 4	5	46					7	2	49	127	14	7	136	. 8	18	74	20	55	33													
	8			21	28	135	. 5	33	39					8	3	36	133	14	32	139	. 8	56	80	21	27	22													
	9		16	9	128	23	26	134	. 6	57	30	18	50	126	9	4	19	136	14	57	142	. 9	31	86	21	58	15												
	10			16	17	133	. 8	5	20	20	34	119		10	4	59	137	15	23	143	. 10	5	90	22	30	12													
	11	朔	1	12	139	16	36	136	. 8	59	12	21	20	109	上弦	11	5	37	135	15	50	143	. 10	37	94	23	2	12											
	12		2	23	146	16	58	138	. 9	45	6	21	58	96		12	6	16	132	16	18	142	. 11	7	97	23	36	16											
	13		3	19	151	17	18	138	. 10	25	10	22	34	84		13	6	56	127	16	47	139	. 11	37	99														
	14		4	9	152	17	37	139	. 11	0	18	23	9	72		14	7	39	121	17	16	134	. 0	11	21	12	10	100											
	15		4	55	148	17	56	141	. 11	31	30	23	45	62		15	8	29	117	17	48	127	. 0	48	29	12	49	102											
	16	上弦	5	40	141	18	13	142	. 11	58	44				16	9	28	115	18	24	118	. 1	30	37	13	47	103												
	17			6	25	132	18	32	144	. 0	22	55	12	23	59	17	10	33	114	19	20	108	. 2	20	45	15	31	101											
	18			7	12	122	18	51	144	. 1	1	52	12	44	73	18	11	27	116	21	25	99	. 3	23	54	17	34	92											
	19			8	7	112	19	11	142	. 1	43	52	13	2	86	19	12	6	120	23	53	100	. 4	37	61	18	37	78											
	20			9	32	103	19	34	138	. 2	34	54	13	8	97	20				12	36	123	. 5	49	68	19	17	61											
	21	下弦				20	2	133	. 3	43	57				望	21	1	23	110	13	3	128	. 6	51	74	19	52	42											
	22					20	45	127	. 5	17	57			22		2	26	120	13	31	133	. 7	44	80	20	28	24												
	23		15	40	122	23	0	122	. 6	47	52	19	12	118		23	3	20	130	13	59	138	. 8	30	87	21	7	8											
	24					15	45	127	. 7	49	44	20	24	111		24	4	11	136	14	31	144	. 9	12	94	21	47	-5											
	25		0	53	126	16	0	131	. 8	35	37	20	58	103		25	5	2	139	15	5	148	. 9	52	100	22	30	-11											
	26	望	1	55	133	16	18	134	. 9	11	31	21	28	94	上弦	26	5	52	137	15	41	150	. 10	29	104	23	14	-11											
	27		2	42	139	16	36	137	. 9	43	27	21	57	84		27	6	44	132	16	20	149	. 11	7	106														
	28		3	24	144	16	53	139	. 10	13	28	22	36	73		28	7	35	126	17	3	144	. 0		5	11	48	105											
	29		4	4	146	17	11	141	. 10	41	32	22	56	62		29	8	25	121	17	50	135	. 0	49	6	12	38	103											
	30		4	45	146	17	28	143	. 11	8	40	23	28	53		30	9	13	118	18	47	122	. 1	39	20	13	45	99											
	31	5	27	143	17	46	145	. 11	35	51																													
9月	1	6	11																																				