

中城湾港
NAKAGUSUKUWANKO

2026 年

満 潮										干 潮										満 潮										干 潮									
日		時 分	cm	時 分	cm	時 分	cm	時 分	cm	日		時 分	cm	時 分	cm	時 分	cm	時 分	cm	時 分	cm	日		時 分	cm	時 分	cm	時 分	cm										
1月	1	望	5 26	163	16 27	186	10 43	93	23 29	-12	4月	1	6 23	190	18 41	192	0 12	26	12 31	32	下弦	11	2 44	133	12 39	134	7 42	115	20 18	59									
	2		6 23	174	17 21	193	11 42	91		2	6 48	194	19 17	191	0 43	33	13 2	22	上弦	12		3 47	144	14 35	140	9 20	103	21 29	53										
	3		7 11	182	18 13	200	0 20	-24	12 32	85	3	7 11	195	19 52	186	1 12	41	13 32		16		朔	13	4 24	157	15 48	154	10 11	86	22 19	45								
	4		7 54	185	19 2	203	1 8	-30	13 18	79	4	7 34	193	20 27	179	1 40	51	14 1		13			朔	14	4 53	170	16 42	171	10 49	67	23 0	39							
	5		8 34	185	19 49	200	1 52	-28	14 2	74	5	7 57	189	21 1	169	2 6	62	14 31		15				下弦	15	5 20	183	17 29	186	11 24	45	23 38	37						
	6	9 12	183	20 34	192	2 34	-19	14 46	71	6	8 22	183	21 38	158	2 33	72	15 3	20	上弦	16	5 48	194	18 13		197			12 0	24										
	7	9 47	179	21 18	179	3 13	-4	15 29	69	7	8 49	175	22 20	146	3 1	83	15 38	29		朔	17	6 17	203		18 58	203	0 14	40	12 37	5									
	8	10 20	175	22 4	163	3 49	15	16 15	68	8	9 19	165	23 15	135	3 31	93	16 19	40			朔	18	6 48		208	19 43	202	0 51	47	13 16	-8								
	9	10 54	170	22 55	145	4 23	35	17 5	69	9	9 55	153			4 10	103	17 15	51				朔	19		7 20	209	20 31	195	1 27	58	13 57	-14							
	10	11 29	164	23 59	130	4 58	55	18 3	68	10	下弦	0 45	129	10 50	142	5 18	113	18 40					59	上弦	20	7 55	205	21 21	182	2 5	71	14 41	-11						
	11	下弦			12 9	158	5 37	74	19 15	66	11		2 44	133	12 39	134	7 42	115	20 18	59	上弦	21	8 33		196	22 18	168	2 44	85	15 30	-1								
	12		1 33	120	13 1	153	6 30	91	20 37	59	12	3 47	144	14 35	140	9 20	103	21 29	53	上弦		22	9 16		184	23 27	155	3 29	98	16 27	14								
	13		3 29	121	14 5	150	7 55	102	21 47	47	13	4 24	157	15 48	154	10 11	86	22 19	45			上弦	23		10 12	169			4 28	109	17 36	30							
	14		4 52	131	15 12	151	9 32	105	22 40	34	14	4 53	170	16 42	171	10 49	67	23 0	39				上弦		24	0 53	149	11 34	154	6 3	114	18 58	43						
	15		5 42	142	16 10	156	10 40	101	23 23	22	15	5 20	183	17 29	186	11 24	45	23 38	37	上弦	25	2 21		152	13 27	149	8 2	107	20 20	49									
16	朔	6 18	151	16 57	164	11 27	95			16	5 48	194	18 13	197			12 0	24	上弦		26	3 23	160	15 3	154	9 23	91	21 27	52										
17		6 50	159	17 39	173	0 0	11	12 5	88	17	朔	6 17	203	18 58	203	0 14	40	12 37			5	上弦	27	4 6	169	16 11	164	10 16	72	22 19	53								
18		7 19	166	18 16	181	0 34	2	12 38	81	18	6 48	208	19 43	202	0 51	47	13 16	-8			上弦		28	4 41	178	17 4	173	10 58	55	23 2	56								
19		7 47	171	18 53	187	1 7	-4	13 11	75	19	7 20	209	20 31	195	1 27	58	13 57	-14					上弦	29	5 11	185	17 48	180	11 34	39	23 39	60							
20		8 15	175	19 29	190	1 38	-6	13 44	69	20	7 55	205	21 21	182	2 5	71	14 41	-11	上弦	30	5 39	190		18 28	184			12 6	27										
21	朔	8 43	178	20 7	189	2 10	-4	14 19	64	21	8 33	196	22 18	168	2 44	85	15 30	-1		上弦	31	6 24	169	17 23	186														
22		9 12	180	20 47	184	2 41	2	14 57	58	22	9 16	184	23 27	155	3 29	98	16 27	14			上弦	26	0 46	133	12 22	163	5 57	87	18 23	45									
23		9 42	180	21 31	175	3 14	13	15 37	54	23	10 12	169			4 28	109	17 36	30				上弦	27	2 46	130	13 39	159	7 26	104	21 17	27								
24		10 13	178	22 20	161	3 47	28	16 23	50	24	上弦	0 53	149	11 34	154	6 3	114	18 58					43	上弦	28	4 35	141	15 7	163	9 26	108	22 30	10						
25		10 48	174	23 22	146	4 23	46	17 16	48	25	2	21	152	13 27	149	8 2	107	20 20	49	上弦	29	5 39	155		16 23	173	10 49	100	23 28	-6									
26	上弦	11 28	169			5 3	67	18 23	45	26	3 23	160	15 3	154	9 23	91	21 27	52	上弦		30	5 39	190	18 28	184														
27		0 46	133	12 22	163	5 57	87	19 48	39	27	4 6	169	16 11	164	10 16	72	22 19	53			上弦	31	6 24	169	17 23	186													
28		2 46	130	13 39	159	7 26	104	21 17	27	28	4 41	178	17 4	173	10 58	55	23 2	56				上弦	26	0 46	133	12 22	163	5 57	87	18 23	45								
29		4 35	141	15 7	163	9 26	108	22 30	10	29	5 11	185	17 48	180	11 34	39	23 39	60					上弦	27	2 46	130	13 39	159	7 26	104	21 17	27							
30		5 39	155	16 23	173	10 49	100	23 28	-6	30	5 39	190	18 28	184						上弦	28	4 35		141	15 7	163	9 26	108	22 30	10									
31	6 24	169	17 23	186	11 45	88				31	6 24	169	17 23	186							上弦	29	5 39	155	16 23	173	10 49	100	23 28	-6									
2月	1	望	7 2	179	18 14	196	0 16	-17	12 30	75	5月	1	6 5	193	19 6	185	0 12	65	12 37	18		下弦	11	2 22	157	13 48	147	8 18	100	20 19	65								
	2		7 36	185	19 0	201	0 59	-22	13 10	63		2	望	6 31	193	19 41	183	0 43	71	13 7			13	上弦	12	3 10	167	15 9	157	9 19	82	21 20	65						
	3		8 7	188	19 20	200	1 37	-19	13 48	54		3	6 57	192	20 16	178	1 13	77	13 38	11			上弦		13	3 49	178	16 13	171	10 6	60	22 12	65						
	4		8 36	189	20 22	193	2 12	-9	14 25	48		4	7 25	189	20 51	172	1 43	83	14 9	14					上弦	14	4 24	189	17 8	185	10 49	36	22 59	67					
	5		9 3	187	21 0	181	2 43	5	15 1	45		5	7 54	184	21 28	165	2 14	89	14 43	19	上弦					15	5 0	199	18 0	195	11 31	14	23 43	71					
	6	下弦	9 29	183	21 39	165	3 12	23	15 37	45		6	8 25	178	22 9	157	2 46	95	15 19	28		上弦	16	5 36	207	18 50	201	0 26	77	12 14	-3								
	7		9 54	177	22 20	148	3 40	41	16 15	48		7	9 1	170	23 0	151	3 23	101	16 0	38			上弦	17	6 14	212	19 40	201	1 10	85	13 46	-17							
	8		10 21	170	23 9	132	4 6	59	16 58	52		8	9 43	161			4 10	108	16 50	48				上弦	18	6 55	213	20 31	196	1 10	87	13 46	-17						
	9		10 51	160			4 34	77	17 53	57		9	0 4	148	10 41	151	5 19	112	17 53	57					上弦	19	7 38	210	21 24	188	1 54	92	14 35	-12					
	10		0 23	118	11 30	150	5 8	93	19 14	59		10	下弦	1 18	150	12 8	145	6 53	111	19 7	63	上弦	20	8 26		202	22 19	179	2 42	99	15 27	0							
	11	朔	2 46	114	12 36	141	6 15	108	20 58	55		11		2 22	157	13 48	147	8 18	100	20 19	65		上弦	21	9 19	190	23 18	172	3 36	105	16 22	16							
	12		4 49	124	14 20	138	8 57	112	22 14	43		12	3 10	167	15 9	157	9 19	82	21 20	65	上弦			22	10 21	177			4 41	108	17 21	34							
	13		5 33	137	15 46	145	10 28	105	23 3	30		13	3 49	178	16 13	171	10 6	60	22 12	65				上弦	23	0 20	168	11 37	164	6 0	106	18 24	51						
	14		6 2	149	16 43	157	11 15	94	23 41	17		14	4 24	189	17 8	185	10 49	36	22 59	67					上弦	24	1 21	168	13 5	156	7 24	99	19 29	65					
	15		6 28	159	17 27	170	11 50	83				15	5 0	199	18 0	195	11 31	14	23 43	71	上弦	25	2 16	171		14 33	155	8 39	86	20 33	76								
	16	朔	6 53	169	18 6	183	0 15	7	12 22	72	16	朔	5 36	207	18 50	201	0 26	77	12 14	-3		上弦	26	3 3	176	15 47	159	9 39	71	21 31	84								
17	7 18		178	18 43	192	0 46	0	12 54	60	17	6 14	212																											

中城湾港
NAKAGUSUKUWANKO

2026 年

満 潮										干 潮										満 潮										干 潮									
日	時 分			cm	時 分			cm	時 分			cm	時 分			cm	日	時 分			cm	時 分			cm	時 分			cm										
7月	1	6 53	201		20 28	189	.	1 16	107	13 44	26	10月	1	9 42	191	21 2	208	3 10	28	15 5	102																		
	2	7 30	203		20 59	191	.	1 50	104	14 17	28		2	10 42	173	21 43	195	4 0	37	15 45	119																		
	3	8 6	202		21 30	191	.	2 25	103	14 50	33		3	下弦	12 9	160	22 43	180	5 4	50	16 46	133																	
	4	8 45	198		22 2	192	.	3 3	101	15 24	41		4			14 16	159	6 33	60	19 6	139																		
	5	9 27	192		22 36	192	.	3 44	99	15 59	51	5		0 36	169	15 40	170	8 14	61	21 11	125																		
	6	10 16	184		23 13	192	.	4 31	96	16 37	64	6		2 38	174	16 25	183	9 32	55	22 12	104																		
	7	11 14	175		23 55	191	.	5 24	91	17 20	79	7		3 55	187	17 0	195	10 27	49	22 56	83																		
	8	下弦		12 28	187	.	6 26	84	18 13	96	8		4 52	201	17 30	205	11 10	47	23 33	64																			
	9		0 43	191		13 59	163	.	7 36	74	19 20	111	9		5 38	211	17 58	212	11 48	48																			
	10		1 41	192		15 34	168	.	8 49	59	20 43	121	10		6 20	215	18 24	216	0 8	48	12 21	54																	
	11		2 45	195		16 54	179	.	9 58	42	22 4	124	11	朔	6 59	214	18 49	217	0 41	36	12 52	63																	
	12		3 50	203		17 56	191	.	10 59	24	23 11	120	12		7 37	209	19 14	214	1 13	29	13 22	73																	
	13	朔	4 52	212		18 47	201	.	11 54	10			13		8 13	200	19 39	209	1 44	27	13 50	84																	
	14		5 49	222		19 33	208	.	0 6	114	12 45	1	14		8 49	189	20 4	202	2 15	29	14 18	94																	
	15		6 42	229		20 14	212	.	0 56	106	13 32	0	15		9 27	177	20 31	192	2 48	36	14 47	104																	
	16		7 32	230		20 52	213	.	1 43	98	14 16	6	16		10 10	165	21 2	181	3 24	45	15 19	113																	
	17		8 20	226		21 28	211	.	2 28	92	14 57	19	17		11 7	154	21 39	168	4 6	57	16 0	123																	
	18		9 7	215		22 1	208	.	3 12	88	15 35	38	18	上弦	12 37	147	22 37	156	5 2	69	17 17	131																	
	19		9 54	200		22 34	203	.	3 58	86	16 11	59	19			14 28	151	6 25	78	19 42	130																		
	20		10 45	183		23 8	198	.	4 45	86	16 46	80	20			0 30	147	15 29	161	8 2	78	21 12	117																
	21	上弦	11 44	166		23 44	191	.	5 39	87	17 22	100	21		2 27	152	16 5	172	9 12	73	21 59	99																	
	22				13 4	154	.	6 42	87	18 9	118	22		3 38	165	16 33	184	10 2	66	22 35	80																		
	23		0 30	184		14 52	151	.	7 59	85	19 22	131	23		4 29	180	17 0	195	10 41	61	23 8	59																	
	24		1 31	178		16 29	158	.	9 16	78	21 4	136	24		5 13	194	17 26	205	11 17	58	23 41	38																	
	25		2 44	177		17 27	168	.	10 19	68	22 23	132	25		5 55	205	17 53	213	11 52	59																			
	26		3 51	181		18 6	178	.	11 8	57	23 15	126	26	望	6 37	211	18 23	219	0 16	20	12 27	64																	
	27		4 44	188		18 38	186	.	11 48	47	23 55	118	27		7 20	212	18 54	220	0 52	6	13 2	72																	
	28	望	5 28	197		19 7	193	.			12 23	39	28		8 5	206	19 28	217	1 31	-2	13 38	83																	
	29		6 7	206		19 34	198	.	0 28	111	12 55	34	29		8 53	195	20 5	210	2 14	-2	14 16	95																	
	30		6 43	212		20 1	203	.	1 1	104	13 26	32	30		9 46	182	20 47	199	3 1	6	14 59	106																	
	31		7 19	216		20 27	207	.	1 33	98	13 56	33	31		10 50	169	21 39	184	3 54	20	15 53	117																	
8月	1	7 55	217		20 54	210	.	2 6	92	14 26	38	11月	1		12 11	161	22 54	168	4 59	36	17 17	123																	
	2	8 33	213		21 21	211	.	2 41	86	14 56	47		2	下弦			13 39	161	6 19	50	19 17	118																	
	3	9 14	206		21 50	210	.	3 18	81	15 27	60		3		0 44	159	14 48	168	7 43	58	20 49	102																	
	4	9 59	195		22 21	207	.	3 59	77	16 0	76		4		2 28	162	15 36	178	8 55	61	21 49	81																	
	5	10 53	182		22 57	202	.	4 46	75	16 37	94		5		3 44	171	16 14	187	9 52	63	22 34	61																	
	6	下弦	12 4	169		23 44	196	.	5 44	73	17 23	113	6		4 42	180	16 46	194	10 38	66	23 13	43																	
	7				13 46	181	.	6 59	71	18 33	131	7		5 30	188	17 16	199	11 18	69	23 47	29																		
	8		0 51	191		15 45	167	.	8 29	63	20 28	140	8		6 12	192	17 45	202	11 54	74																			
	9		2 20	191		17 4	181	.	9 52	49	22 9	135	9	朔	6 51	193	18 12	202	0 20	18	12 27	79																	
	10		3 46	200		17 55	195	.	10 56	33	23 13	123	10		7 28	190	18 40	200	0 52	13	12 58	84																	
	11		4 53	214		18 35	207	.	11 49	20			11		8 4	185	19 8	196	1 23	11	13 29	89																	
	12	朔	5 49	227		19 11	215	.	0 3	108	12 35	13	12		8 39	179	19 38	190	1 55	14	14 0	94																	
	13		6 38	235		19 44	221	.	0 46	94	13 16	14	13		9 15	171	20 9	183	2 29	20	14 32	100																	
	14		7 24	236		20 15	223	.	1 26	83	13 53	23	14		9 56	162	20 44	173	3 4	28	15 9	105																	
	15		8 6	231		20 44	222	.	2 5	75	14 27	37	15		10 43	155	21 25	163	3 44	39	15 55	110																	
	16		8 48	219		21 11	218	.	2 43	70	14 58	55	16	上弦	11 42	151	22 19	151	4 30	50	17 2	114																	
	17		9 29	203		21 37	212	.	3 21	69	15 27	75	17			12 53	152	23 42	142	5 28	61	18 35	112																
	18		10 12	186		22 4	204	.	4 1	72	15 56	93	18				13 58	157	6 38	68			20 4	102															
	19	上弦	11 3	168		22 35	194	.	4 44	77	16 25	111	19		1 26	141	14 48	165	7 52	72	21 6	84																	
	20		12 14	154		23 13	183	.	5 37	84	17 1	127	20		2 53	149	15 27	175	8 56	73	21 52	62																	
	21				14 23	149	.	6 53	88	18 10	140	21		3 58	162	16 3	185	9 50	73	22 33	39																		
	22		0 17	173		16 25	157	.	8 34	87	20 43	144	22		4 52	175	16 37	195	10 37	73	23 13	17																	
	23		2 2	168		17 14	169	.	9 55	77	22 15	136	23		5 41	187	17 13	203	11 20	75	23 54	-3																	
	24		3 33	175		17 45	180	.	10 47	65	23 2	125	24	望	6 29	194	17 50	209			12 2	78																	
	25		4 31	186		18 11	190	.	11 27	54	23 37	113	25			7 17	196	18 30	212	0 36	-16	12 44	82																
	26		5 15	199		18 35	199	.			12 0	45	26	26		8 5	194	19 12	210	1 21	-22	13 28	88																
	27		5 53	210		18 59	207	.	0 8	102	12 30	40		27		8 55	187	19 58	204	2 8	-20	14 13	93																
	28		6 29	219		19 23	214	.	0 38	90	12 59	38		28		9 47	179	20 49	193	2 58	-11	15 4	97																
	29		7 5	224		19 47	219	.	1 9	79	13 28	40		29		10 43	171	21 46	179	3 50	4	16 4	100																
	30		7 41	225		20 11	222	.	1 41	69	13 56	47		30		11 41	166	22 57	164	4 46	22	17 18	100																
	31		8 20	220		20 37	222	.	2 15	60	14 26	58																											
9月	1		9 1	211		21 5	219	.	2 51	55	14 56	73	12月	1	下弦			12 42	164	5 47	41	18 43	94																
	2		9 46	197		21 35	212	.	3 31	53	15 28	90		2		0 24	151	13 40	165	6 52	58	20 7	81																
	3		10 41	181		22 11	203	.	4 17	56	16 3	109		3		2 0	146	14 33	169	7 59	71	21 15	65																
	4	下弦	11 57	165		23 0	192	.	5 16	62	16 48	127		4	3 25	149	15 19	173	9 4	80	22 8	48																	
	5				14 4	158	.	6 40	68	18 18	143	5			4 32	156	16 0	177	10 1	85	22 52	32																	
	6		0 25	182		16 2	169	.	8 24	65	20 57	142	6		5 26	164	16 38	181	10 50	87	23 30	20																	
	7		2																																				